FLI Software Development Library

- Version 1.2 -

Windows and Linux support for FLI CCD cameras, filter wheels, and focusers.

Finger Lakes Instrumentation Copyright (c) 2000-2002 Finger Lakes Instrumentation (FLI), LLC. All rights reserved.

Contents

1	Introduction	4
2	Library Defined Types	5
3	Library Functions	9

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

May 19, 2003

FLI Software Development Library

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

May 19, 2003

Introduction

This library provides a core set of functions for programming FLI CCD cameras, filter wheels, and focusers under Windows and Linux. The type definitions, function prototypes, and definitions/enumerations of constant values used by library functions are spcified in libfli.h. All library functions return zero on successful completion, and non-zero if an error occurred. The exact nature of an error can be found by treating the negative of a function's return value as a system error code, for example:

```
if ((err = FLIOpen(&dev, name, domain)))
{
    fprintf(stderr, "Error FLIOpen: %s\n", strerror((int)-err));
    exit(1);
}
```

```
This page was generated with the help of DOC++
http://www.linuxsupportline.com/~doc++
```

4

Library Defined Types

Names

2.1	typedef long		
	flidev_t	An opaque handle used by library functions to refer to FLI hardware .	5
2.2	typedef long flidomain_t	The domain of an FLI device	6
2.3	typedef long fliframe_t	The frame type for an FLI CCD cam- era device.	6
2.4	typedef long flibitdepth_t	The gray-scale bit depth for an FLI camera device.	6
2.5	typedef long flishutter_t	Type used for shutter operations for an FLI camera device.	7
2.6	typedef long flibgflush_t	<i>Type used for background flush oper-</i> <i>ations for an FLI camera device.</i>	7
2.7	typedef long flidebug_t	Type specifying library debug levels.	8

_____ 2.1

typedef long flidev_t

An opaque handle used by library functions to refer to FLI hardware

An opaque handle used by library functions to refer to FLI hardware

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

5

_____ 2.2 ______typedef long **flidomain_t**

The domain of an FLI device.

The domain of an FLI device. This consists of a bitwise ORed combination of interface method and device type. Valid interfaces are FLIDOMAIN_PARALLEL_PORT, FLIDOMAIN_USB, FLIDOMAIN_SERIAL, and FLIDOMAIN_INET. Valid device types are FLIDEVICE_CAMERA, FLIDOMAIN_FILTERWHEEL, and FLIDOMAIN_FOCUSER.

See Also: FLIOpen FLIList (\rightarrow 3.32, page 30)

typedef long fliframe_t

_ 2.3 _

The frame type for an FLI CCD camera device.

The frame type for an FLI CCD camera device. Valid frame types are FLI_FRAME_TYPE_NORMAL and FLI_FRAME_TYPE_DARK.

See Also:

2.4

FLISetFrameType (\rightarrow 3.15, *page 21*)

typedef long flibitdepth_t

The gray-scale bit depth for an FLI camera device.

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

The gray-scale bit depth for an FLI camera device. Valid bit depths are FLI_MODE_8BIT and FLI_MODE_16BIT.

See Also: FLISetBitDepth (\rightarrow 3.24, page 26)

typedef long flishutter_t

Type used for shutter operations for an FLI camera device.

Type used for shutter operations for an FLI camera device. Valid shutter types are FLI_SHUTTER_CLOSE, FLI_SHUTTER_OPEN, FLI_SHUTTER_EXTERNAL_TRIGGER, FLI_SHUTTER_EXTERNAL_TRIGGER_LOW, and FLI_SHUTTER_EXTERNAL_TRIGGER_HIGH.

See Also: FLIControlShutter

_____ 2.6 _____

typedef long flibgflush_t

Type used for background flush operations for an FLI camera device.

Type used for background flush operations for an FLI camera device. Valid bgflush types are FLI_BGFLUSH_STOP and FLI_BGFLUSH_START.

See Also: FLIControlBackgroundFlush

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

2.5

_____ 2.7 _____ typedef long **flidebug_t**

Type specifying library debug levels.

Type specifying library debug levels. Valid debug levels are FLIDEBUG_NONE, FLIDEBUG_INFO, FLIDEBUG_WARN, and FLIDEBUG_FAIL.

See Also: FLISetDebugLevel (\rightarrow 3.2, page 13)

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

May 19, 2003

Library Functions

Names

3.1	LIBFLIAPI FLIOpen (flidev_t* o flidomain	lev, char* name, _t domain) <i>Get a handle to an FLI device.</i>	12
3.2	LIBFLIAPI FLISetDebugLevel (12
3.3	LIBFLIAPI FLIClose (flidev_t de	ev) Close a handle to a FLI device	14
3.4	LIBFLIAPI FLIGetLibVersion (char* ver, size_t len) Get the current library version	14
3.5	LIBFLIAPI FLIGetModel (flide	v_t dev, char* model, size_t len) Get the model of a given device	15
3.6	LIBFLIAPI FLIGetPixelSize (fli do	dev_t dev, double* pixel_x, puble* pixel_y) Find the dimensions of a pixel in the array of the given device	15
3.7	LIBFLIAPI FLIGetHWRevisior	(flidev_t dev, long* hwrev) Get the hardware revision of a given device	16
3.8	LIBFLIAPI FLIGetFWRevision	(flidev_t dev, long* fwrev) Get firmware revision of a given de- vice	17
3.9	-	flidev_t dev, long* ul_x, long* ul_y, long* lr_x, long* lr_y) Get the array area of the given cam- era.	17
3.10	LIBFLIAPI FLIGetVisibleArea	(flidev_t dev, long* ul_x, long* ul_y, long* lr_x, long* lr_y) Get the visible area of the given cam- era.	18
3.11	LIBFLIAPI FLISetExposureTin		18
3.12	LIBFLIAPI FLISetImageArea (1	flidev_t dev, long ul_x, long ul_y, long lr_x, long lr_y)	

This page was generated with the help of DOC++

http://www.linuxsupportline.com/~doc++

9

		Set the image area for a given camera.	19
3.13	LIBFLIAPI FLISetHBin (flidev.	t dev, long hbin) Set the horizontal bin factor for a given camera.	20
3.14	LIBFLIAPI FLISetVBin (flidev.	t dev, long vbin) Set the vertical bin factor for a given camera.	20
3.15	LIBFLIAPI FLISetFrameType	(flidev_t dev, fliframe_t frametype) Set the frame type for a given camera.	21
3.16	LIBFLIAPI FLICancelExposur		21
3.17	LIBFLIAPI FLIGetExposureSt	atus (flidev 1 dev, long* timeleft) Find the remaining exposure time of a given camera.	22
3.18	LIBFLIAPI FLISetTemperature	e (flidev_t dev, double temperature) Set the temperature of a given cam- era.	22
3.19	LIBFLIAPI FLIGetTemperatur	e (flidev_t dev, double* temperature) Get the temperature of a given cam- era.	23
3.20	LIBFLIAPI FLIGrabRow (flide	v_t dev, void* buff, size_t width) Grab a row of an image	23
3.21	LIBFLIAPI FLIExposeFrame (#	flidev_t dev) Expose a frame for a given camera.	24
3.22	LIBFLIAPI FLIFlushRow (flide	v_t dev, long rows, long repeat) Flush rows of a given camera	25
3.23	LIBFLIAPI FLISetNFlushes (fli	dev_t dev, long nflushes) Set the number of flushes for a given camera.	25
3.24	LIBFLIAPI FLISetBitDepth (fli	dev_t dev, flibitdepth_t bitdepth) Set the gray-scale bit depth for a given camera.	26
3.25	LIBFLIAPI FLIReadIOPort (fli	•	26
3.26	LIBFLIAPI FLIWriteIOPort (fl		20

This page was generated with the help of DOC++

		Write to the I/O port of a given camera.	27
3.27	LIBFLIAPI FLIConfigureIOP	U U U U U U U U U U U U U U U U U U U	
		Configure the I/O port of a given camera.	27
3.28	LIBFLIAPI FLILockDevice (fli		
		Lock a specified device.	28
3.29	LIBFLIAPI FLIUnlockDevice (flidev_t dev) Unlock a specified device	28
3.30	LIBFLIAPI FLIControlShutter	(flidev_t dev, flishutter_t shutter)	
		Control the shutter on a given camera.	29
3.31	LIBFLIAPI FLIControlBackgr	roundFlush (flidev_t dev,	
		flibgflush_t bgflush) Enables background flushing of CCD	
		array.	29
3.32	LIBFLIAPI FLIList (flidomain_	t domain, char*** names)	
		List available devices	30
3.33	LIBFLIAPI FLIFreeList (char*		
		Free a previously generated device list.	31
3.34	LIBFLIAPI FLISetFilterPos (fl	idev_t dev, long filter)	
		Set the filter wheel position of a given	21
2.25		device.	31
3.35	LIBFLIAPI FLIGetFilterPos (f	Get the filter wheel position of a	
		given device.	32
3.36	LIBFLIAPI FLIGetFilterCoun		
		Get the filter wheel filter count of a given device.	32
3.37	LIBFLIAPI FLIStepMotor (flid	lev_t dev, long steps)	
		Step the filter wheel or focuser motor	20
3.38	LIDELIADI ELICAtStannarDag	of a given device.	32
3.30	LIDTLIARI FLIGeistepperros	ition (flidev_t dev, long* position) Get the stepper motor position of a	
		given device.	33
3.39	LIBFLIAPI FLIHomeFocuser (flidev_t dev) Home a given focuser.	33
3.40	LIBFLIAPI FLICreateList (flid	0 1	55
5.40		omani uomani)	

This page was generated with the help of DOC++

http://www.linuxsupportline.com/~doc++

	Creates a list of all devices within a specified domain.	34
3.41	LIBFLIAPI FLIDeleteList (void)	
	Deletes a list of devices created by FLICreateList()	34
3.42	LIBFLIAPI FLIListFirst (flidomain_t* domain, char* filename, size_t fnlen, char* name, size_t namelen) <i>Obtains the first device in the list.</i>	35
3.43	LIBFLIAPI FLIListNext (flidomain_t* domain, char* filename, size_t fnlen, char* name, size_t namelen)	
	<i>Obtains the next device in the list.</i> .	35

LIBFLIAPI FLIOpen (flidev_t* dev, char* name, flidomain_t domain)

Get a handle to an FLI device.

Get a handle to an FLI device. This function requires the filename and domain of the requested device. Valid device filenames can be obtained using the FLIList() function. An application may use any number of handles associated with the same physical device. When doing so, it is important to lock the appropriate device to ensure that multiple accesses to the same device do not occur during critical operations.

Return Value:

on success. Non-zero on failure.

Zero

_ 3.1 _

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

Parameters:	dev	Pointer to where a device handle will be placed.
	name	Pointer to a string where the device file- name to beopened is stored. For par- allel port devices that are not probed byFLIList() (Windows 95/98/Me), place the address of theparallel port in a string in ascii form ie: "0x378".
	domain	Domain to apply to name for device opening.This is a bitwise ORed com- bination of interface method and devicetype. Valid interfaces include FLIDOMAIN_PARALLEL_PORT,FLIDOMAIN_USB, FLIDOMAIN_SERIAL, andFLIDOMAIN_INET. Valid device types in- cludeFLIDEVICE_CAMERA, FLIDOMAIN_FILTERWHEEL, andFLIDOMAIN_FOCUSER.
See Also:	FLIList FLIClose flidomain_t	

3.2 _____ 3.2 _____ LIBFLIAPI **FLISetDebugLevel** (char* host, flidebug_t level)

Enable debugging of API operations and communications.

Enable debugging of API operations and communications. Use this function in combination with FLIDebug to assist in diagnosing problems that may be encountered during programming.

Return Value:	Zero	on success.
	Non-zero	on failure.

This page was generated with the help of DOC++

http://www.linuxsupportline.com/~doc++

May 19, 2003

Parameters:	host	Name of the file to send debugging in- formation to. This parameter is ignored un- der Linux where syslog(3) isused to send debug messages (see syslog.conf(5) for how toconfigure syslogd).
	level	Debug level. A value of FLIDEBUG_NONE disablesdebugging. Values of FLIDEBUG_FAIL, FLIDEBUG_WARN, andFLIDEBUG_INFO enable progressively more verbose debug messages.

LIBFLIAPI **FLIClose** (flidev_t dev)

Close a handle to a FLI device

Close a handle to a FLI device

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev The	levice handle to be closed.
See Also:	FLIOpen	

_____ 3.4 ____

LIBFLIAPI FLIGetLibVersion (char* ver, size_t len)

Get the current library version.

Get the current library version. This function copies up to len - 1 characters of the current library version string followed by a terminating NULL character into the buffer pointed to by ver.

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

May 19, 2003

14

3.3

Return Value:	Zero Non-zero	on success. on failure.	
Parameters:	ver Pointer to a character buffer where the brary versionstring is to be placed.		
		n The size in bytes of the buffer pointed to byver.	

_____ 3.5

LIBFLIAPI **FLIGetModel** (flidev_t dev, char* model, size_t len)

Get the model of a given device.

Get the model of a given device. This function copies up to len - 1 characters of the model string for device dev, followed by a terminating NULL character into the buffer pointed to by model.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev I	Device to find model of.
	model H	Pointer to a character buffer where the
	r	nodel stringis to be placed.
	len 7	The size in bytes of buffer pointed to
	t	ymodel.
See Also: FLIGetHWRevision		Revision
]	FLIGetFWI	Revision
]	FLIGetSeri	alNum

______3.6

LIBFLIAPI **FLIGetPixelSize** (flidev_t dev, double* pixel_x, double* pixel_y)

Find the dimensions of a pixel in the array of the given device

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++ 3

Find the dimensions of a pixel in the array of the given device

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev	Device to find the pixel size of.
	pixel_x	Pointer to a double which will receive the size (inmicrons) of a pixel in the x direction.
	pixel_y	Pointer to a double which will receive the size (inmicrons) of a pixel in the y direction.
See Also:	FLIGetArra FLIGetVisi	

_____ 3.7 ____

LIBFLIAPI **FLIGetHWRevision** (flidev_t dev, long* hwrev)

Get the hardware revision of a given device

Get the hardware revision of a given device

Return Value:	Zero	on success.			
	Non-zero	o on failure.			
Parameters:	dev	Device to find the hardware revision of.			
	hwrev	Pointer to a long which will receive the			
		hardwarerevision.			
See Also:	FLIGetMo	del			
]	FLIGetFWRevision				
]	FLIGetSerialNum				

LIBFLIAPI **FLIGetFWRevision** (flidev_t dev, long* fwrev)

Get firmware revision of a given device

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

. 3.8 .

May 19, 2003

3

3.9

Get firmware revision of a given device

Return Value:	Zero	on success.				
	Non-zero	on failure.				
Parameters:	dev	Device to find the firmware revision of.				
	fwrev	Pointer to a long which will receive the				
	:	firmwarerevision.				
See Also:	FLIGetMo	del				
]	FLIGetHWRevision					
]	FLIGetSeri	ialNum				

LIBFLIAPI **FLIGetArrayArea** (flidev_t dev, long* ul_x, long* ul_y, long* lr_x, long* lr_y)

Get the array area of the given camera.

Get the array area of the given camera. This function finds the *total* area of the CCD array for camera dev. This area is specified in terms of a upper-left point and a lower-right point. The upper-left x-coordinate is placed in ul_x, the upper-left y-coordinate is placed in ul_y, the lower-right x-coordinate is placed in lr_x, and the lower-right y-coordinate is placed in lr_y.

Return Value:	Zero	on	succ	ess.			
	Non-z	ero on	failu	re.			
Parameters:	dev	Camera	to ge	et the arr	ay are	ea of.	
	ul_x	Pointer	to	where	the	upper-left	Х-
		coordina	ate is	to bepla	iced.		
	ul_y	Pointer	to	where	the	upper-left	y-
		coordina	ate is	to bepla	iced.		
	lr_x	Pointer	to	where	the	lower-right	Х-
		coordina	ate is	to bepla	iced.		
	lr_y	Pointer	to	where	the	lower-right	y-
		coordina	ate is	to bepla	iced.		
See Also:	FLIGet	VisibleAr	ea				
	FLISetI	mageArea	a				

This page was generated with the help of DOC++

____ 3.10 _____ LIBFLIAPI **FLIGetVisibleArea** (flidev_t dev, long* ul_x, long*

ul_y, long* lr_x, long* lr_y)

Get the visible area of the given camera.

Get the visible area of the given camera. This function finds the *visible* area of the CCD array for the camera dev. This area is specified in terms of a upper-left point and a lower-right point. The upper-left x-coordinate is placed in ul_x, the upper-left y-coordinate is placed in ul_y, the lower-right x-coordinate is placed in lr_x, the lower-right y-coordinate is placed in lr_y.

Return Value:	Zero	on	succ	ess.			
	Non-ze	ero on	failu	re.			
Parameters:	dev	Camera	to ge	et the vis	ible a	rea of.	
	ul_x	Pointer	to	where	the	upper-left	Х-
		coordina	ate is	to bepla	ced.		
	ul_y	Pointer	to	where	the	upper-left	у-
		coordina	ate is	to bepla	ced.		
	lr <u></u> x	Pointer	to	where	the	lower-right	Х-
		coordina	ate is	to bepla	ced.		
	lr_y	Pointer	to	where	the	lower-right	у-
		coordina	ate is	to bepla	ced.		
See Also:	FLIGetA	ArrayArea	a				
]	FLISetIı	mageArea	a				

_____ 3.11 _

LIBFLIAPI FLISetExposureTime (flidev_t dev, long exptime)

Set the exposure time for a camera.

Set the exposure time for a camera. This function sets the exposure time for the camera dev to exptime msec.

This page was generated with the help of DOC++

Return Value:	Zero Non-zero	on success. on failure.				
Parameters:	dev	Camera to set the exposure time of.				
	exptime	Exposure time in msec.				
See Also:	FLIExposeF	Trame				
	FLICancelExposure					
	FLIGetExposureStatus					

_ 3.12

LIBFLIAPI **FLISetImageArea** (flidev_t dev, long ul_x, long ul_y, long lr_x, long lr_y)

Set the image area for a given camera.

Set the image area for a given camera. This function sets the image area for camera dev to an area specified in terms of a upper-left point and a lower-right point. The upper-left x-coordinate is ul_x, the upper-left y-coordinate is ul_y, the lower-right x-coordinate is lr_x , and the lower-right y-coordinate is lr_y . Note that the given lower-right coordinate must take into account the horizontal and vertical bin factor settings, but the upper-left coordinate is absolute. In other words, the lower-right coordinate used to set the image area is a virtual point (lr'_x, lr'_y) determined by:

 $lr'_{x} = ul_{x} + (lr_{x} - ul_{x})/hbin$ $lr'_{y} = ul_{y} + (lr_{y} - ul_{y})/vbin$

Where (lr'_x, lr'_y) is the coordinate to pass to the FLISetImageArea function, (ul_x, ul_y) and (lr_x, lr_y) are the absolute coordinates of the desired image area, *hbin* is the horizontal bin factor, and *vbin* is the vertical bin factor.

Return Value:	Zero	on success.				
	Non-ze	ero on failure.				
Parameters:	dev	Camera to set image area of.				
	ul_x	Upper-left x-coordinate of image area.				
	ul_y	Upper-left y-coordinate of image area.				
	lr_x	x Lower-right x-coordinate of image area (<i>l</i>				
		fromabove).				
	lr_y	Lower-right y-coordinate of image area (lr'_y)				
		fromabove).				

This page was generated with the help of DOC++

See Also:

FLIGetVisibleArea FLIGetArrayArea

LIBFLIAPI **FLISetHBin** (flidev_t dev, long hbin)

Set the horizontal bin factor for a given camera.

Set the horizontal bin factor for a given camera. This function sets the horizontal bin factor for the camera dev to hbin. The valid range of the hbin parameter is from 1 to 16.

Return Value:	Zero	on success.			
	Non-zero	on failure.			
Parameters:	dev Can	nera to set horizontal bin factor of.			
	hbin Hor	izontal bin factor.			
See Also:	FLISetVBin				
	FLISetImage	Area			

_____ 3.14 _

LIBFLIAPI FLISetVBin (flidev_t dev, long vbin)

Set the vertical bin factor for a given camera.

Set the vertical bin factor for a given camera. This function sets the vertical bin factor for the camera dev to vbin. The valid range of the vbin parameter is from 1 to 16.

Return Value:	Zero		on success.
	Non-ze	ro	on failure.
Parameters:			era to set vertical bin factor of. ical bin factor.

This page was generated with the help of DOC++

http://www.linuxsupportline.com/~doc++

May 19, 2003

3.13

See Also:

FLISetHBin FLISetImageArea

_____ 3.15 _____ LIBFLIAPI **FLISetFrameType** (flidev_t dev, fliframe_t frametype)

Set the frame type for a given camera.

Set the frame type for a given camera. This function sets the frame type for camera dev to frametype. The frametype parameter is either FLI_FRAME_TYPE_NORMAL for a normal frame where the shutter opens or FLI_FRAME_TYPE_DARK for a dark frame where the shutter remains closed.

Zero	on success.	
Non-zero	on failure.	
cam	Camera to set	the frame type of.
frametype	Frame type:	FLI_FRAME_TYPE_NORMAL or
	FLI_FRAME_T	YPE_DARK.
fliframe_t		
FLIExposeFr	ame	
	Non-zero cam frametype fliframe_t	Non-zero on failure. cam Camera to set frametype Frame type: FLI_FRAME_T

LIBFLIAPI FLICancelExposure (flidev_t dev)

Cancel an exposure for a given camera.

Cancel an exposure for a given camera. This function cancels an exposure in progress by closing the shutter.

Return Value:	Zero	on success.		
	Non-zero	on failure.		
Parameters:	dev Came	era to cancel the exposure of.		

This page was generated with the help of DOC++

http://www.linuxsupportline.com/~doc++

3.16

May 19, 2003

See Also:

FLIExposeFrame FLIGetExposureStatus FLISetExposureTime

3.17			
LIBFLIAPI FLIGetExposureStatus (flidev_t	dev,	long*	
timeleft)			

Find the remaining exposure time of a given camera.

Find the remaining exposure time of a given camera. This functions places the remaining exposure time (in milliseconds) in the location pointed to by timeleft.

Zero	on success.
Non-zero	on failure.
dev	Camera to find the remaining exposure time
	of.
timeleft	Pointer to where the remaining exposure
	time (in milliseonds) will be placed.
FLIExposeFr	ame
FLICancelEx	posure
FLISetExpos	ureTime
	Non-zero dev timeleft FLIExposeFr FLICancelEx

_ 3.18 .

LIBFLIAPI **FLISetTemperature** (flidev_t dev, double temperature)

Set the temperature of a given camera.

Set the temperature of a given camera. This function sets the temperature of the CCD camera dev to temperature degrees Celsius. The valid range of the temperature parameter is from -55 C to 45 C.

This page was generated with the help of DOC++

Return Value:	Zero	on	success.
	Non-zero	on	failure.
Parameters:	dev		Camera device to set the temperature of.
	temperatur	re	Temperature in Celsius to set CCD camera
			cold finger to.
See Also:	FLIGetTempe	erati	ıre

LIBFLIAPI FLIGetTemperature (flidev_t dev, double* tempera-

ture)

Get the temperature of a given camera.

Get the temperature of a given camera. This function places the temperature of the CCD camera cold finger of device dev in the location pointed to by temperature.

Return Value:	Zero	on	success.
	Non-zero	on	failure.
Parameters:	dev		Camera device to get the temperature of.
	temperatu	re	Pointer to where the temperature will be
			placed.
See Also:	FLISetTempe	eratu	ire

_____ 3.20 _____

LIBFLIAPI FLIGrabRow (flidev_t dev, void* buff, size_t width)

Grab a row of an image.

Grab a row of an image. This function grabs the next available row of the image from camera device dev. The row of width width is placed in the buffer pointed to by buff. The size of the buffer pointed to by buff must take into account the bit depth of

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++ 3

_ 3.21 _

the image, meaning the buffer size must be at least width bytes for an 8-bit image, and at least 2*width for a 16-bit image.

Return Value:	Zero	on success.
	Non-zer	o on failure.
Parameters:	dev	Camera whose image to grab the next avail-
		able row from.
	buff	Pointer to where the next available row will
		be placed.
	width	Row width in pixels.
See Also:	FLIGrabF	rame

LIBFLIAPI FLIExposeFrame (flidev_t dev)

Expose a frame for a given camera.

Expose a frame for a given camera. This function exposes a frame according to the settings (image area, exposure time, bit depth, etc.) of camera dev. The settings of dev must be valid for the camera device. They are set by calling the appropriate set library functions. This function returns after the exposure has started.

Return Value:	Zero	on success.		
	Non-zero	on failure.		
Parameters:	dev Came	era to expose the frame of.		
See Also:	FLISetExposureTime			
	FLISetFrame'	Туре		
	FLISetImage.	Area		
	FLISetHBin			
	FLISetVBin			
	FLISetNFlush	hes		
	FLISetBitDep	oth		
	FLIGrabFram	ne		
	FLICancelEx	posure		
	FLIGetExpos	ureStatus		

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

May 19, 2003

_ 3.22 _

LIBFLIAPI FLIFlushRow (flidev_t dev, long rows, long repeat)

Flush rows of a given camera.

Flush rows of a given camera. This function flushes rows rows of camera dev repeat times.

Return Value:	Zero Non-zero	on success. on failure.
Parameters:	rows	Camera to flush rows of. Number of rows to flush. Number of times to flush each row.
See Also:	FLISetNFlu	shes

LIBFLIAPI FLISetNFlushes (flidev_t dev, long nflushes)

Set the number of flushes for a given camera.

Set the number of flushes for a given camera. This function sets the number of times the CCD array of camera dev is flushed *before* exposing a frame to nflushes. The valid range of the nflushes parameter is from 1 to 16.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev	Camera to set the number of flushes of.
	nflushes	Number of times to flush CCD array before
		anexposure.
See Also:	FLIFlushRow	7
	FLIExposeFr	ame

This page was generated with the help of DOC++

LIBFLIAPI **FLISetBitDepth** (flidev_t dev, flibitdepth_t bitdepth)

Set the gray-scale bit depth for a given camera.

Set the gray-scale bit depth for a given camera. This function sets the gray-scale bit depth of camera dev to bitdepth. The bitdepth parameter is either FLI_MODE_8BIT for 8-bit mode or FLI_MODE_16BIT for 16-bit mode.

Return Value:	Zero	on success.		
	Non-zero	on failure.		
Parameters:	dev	Camera to set the l	bit depth	of.
	bitdepth	Gray-scale bit d	lepth:	FLI_MODE_8BIT
		orFLI_MODE_16BIT	т.	
See Also:	flibitdepth_t			
	FLIExposeFr	ame		

LIBFLIAPI FLIReadIOPort (flidev_t dev, long* ioportset)

Read the I/O port of a given camera.

Read the I/O port of a given camera. This function reads the I/O port on camera dev and places the value in the location pointed to by ioportset.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev	Camera to read the I/O port of.
	ioportset	Pointer to where the I/O port data will be
		stored.
See Also:	FLIWriteIOP	lort
	FLIConfigure	eIOPort

This page was generated with the help of DOC++

http://www.linuxsupportline.com/~doc++

3.24

3.25

LIBFLIAPI FLIWriteIOPort (flidev_t dev, long ioportset)

Write to the I/O port of a given camera.

Write to the I/O port of a given camera. This function writes the value ioportset to the I/O port on camera dev.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev	Camera to write I/O port of.
	ioportset	Data to be written to the I/O port.
See Also:	FLIReadIOP	ort
	FLIConfigure	IOPort

LIBFLIAPI FLIConfigureIOPort (flidev_t dev, long ioportset)

Configure the I/O port of a given camera.

Configure the I/O port of a given camera. This function configures the I/O port on camera dev with the value ioportset.

The I/O configuration of each pin on a given camera is determined by the value of ioportset. Setting a respective I/O bit enables the port bit for output while clearing an I/O bit enables to port bit for input. By default, all I/O ports are configured as inputs.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev	Camera to configure the I/O port of.
	ioportset	Data to configure the I/O port with.
See Also:	FLIReadIOP	ort
	FLIWriteIOP	ort

http://www.linuxsupportline.com/~doc++

_ 3.26 _

3.27

This page was generated with the help of DOC++

3.28

LIBFLIAPI **FLILockDevice** (flidev_t dev)

Lock a specified device.

Lock a specified device. This function establishes an exclusive lock (mutex) on the given device to prevent access to the device by any other function or process.

Return Value:	Zero	on success.	
	Non-zero	on failure.	
Parameters:	dev Devie	ce to lock.	
See Also:	FLIUnlockDevice		

_____ 3.29 ____

LIBFLIAPI FLIUnlockDevice (flidev_t dev)

Unlock a specified device.

Unlock a specified device. This function releases a previously established exclusive lock (mutex) on the given device to allow access to the device by any other function or process.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev Devic	e to unlock.
See Also:	FLILockDevice	

______3.30 _____

LIBFLIAPI FLIControlShutter (flidev_t dev, flishutter_t shutter)

Control the shutter on a given camera.

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

May 19, 2003

3

Control the shutter on a given camera. This function controls the shutter function on camera dev according to the shutter parameter.

Return Value:	Zero Non-zero	on success. on failure.
Parameters:	dev shutter	Device to control the shutter of. How to control the shutter. A value ofFLI_SHUTTER_CLOSE closes the shutter andFLI_SHUTTER_OPEN opens the shut- ter.FLI_SHUTTER_EXTERNAL_TRIGGER_LOW causes the exposure to beginonly when a logic LOW is detected on I/O port bit 0.FLI_SHUTTER_EXTERNAL_TRIGGER_HIGH causes the exposure to beginonly when a logic HIGH is detected on I/O port bit 0. This settingmay not be available on all cameras.
See Also:	flishutter_t	

3.31		
LIBFLIAPI FLIControlBackgroundFlush	(flidev_t	dev,
	flibgflush_t bgflu	ish)

Enables background flushing of CCD array.

Enables background flushing of CCD array. This function enables the background flushing of the CCD array camera dev according to the bgflush parameter. Note that this function may not succeed on all FLI products as this feature may not be available.

Return Value:	Zero	on success.
	Non-zero	on failure.

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

Parameters:	dev	Device to control the background flushing of.
	bgflush	Enables or disables background flush- ing. A value of FLI_BGFLUSH_START begins background flushing. It is impor- tant tonote that background flushing is stopped whenever FLIExposeFrame()or FLIControlShutter() are called. FLI_BGFLUSH_STOP stops allbackground flush activity.
See Also:	flibgflush_t	

_____ 3.32 _____ LIBFLIAPI **FLIList** (flidomain_t domain, char*** names)

List available devices.

List available devices. This function returns a pointer to a NULL terminated list of device names. The pointer should be freed later with FLIFreeList(). Each device name in the returned list includes the filename needed by FLIOpen(), a separating semicolon, followed by the model name or user assigned device name.

Return Value:	Zero Non-zero	on success. on failure.
Parameters:	domain	Domain to list the devices of. This is a bit- wiseORed combination of interface method and device type. Validinterfaces include FLIDOMAIN_PARALLEL_PORT,FLIDOMAIN_USB, FLIDOMAIN_SERIAL, andFLIDOMAIN_INET. Valid device types in- cludeFLIDEVICE_CAMERA, FLIDOMAIN_FILTERWHEEL, andFLIDOMAIN_FOCUSER.
See Also:	names flidomain_t FLIFreeLis FLIOpen	

This page was generated with the help of DOC++

____ 3.33 _____ LIBFLIAPI **FLIFreeList** (char** names)

Free a previously generated device list.

Free a previously generated device list. Use this function after ${\tt FLIList}()$ to free the list of device names.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	names P	ointer to the list.
See Also:	FLIList	

____ 3.34 __

LIBFLIAPI FLISetFilterPos (flidev_t dev, long filter)

Set the filter wheel position of a given device.

Set the filter wheel position of a given device. Use this function to set the filter wheel position of dev to filter.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev H	Filter wheel device handle.
	filter I	Desired filter wheel position.
See Also:	FLIGetFilter	Pos

LIBFLIAPI FLIGetFilterPos (flidev_t dev, long* filter)

Get the filter wheel position of a given device.

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

_ 3.35 _

May 19, 2003

Get the filter wheel position of a given device. Use this function to get the filter wheel position of dev.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev I	Filter wheel device handle.
	filter H	Pointer to where the filter wheel position
	v	vill beplaced.
See Also:	FLISetFilterl	Pos

____ 3.36 _____ LIBFLIAPI **FLIGetFilterCount** (flidev_t dev, long* filter)

Get the filter wheel filter count of a given device.

Get the filter wheel filter count of a given device. Use this function to get the filter count of filter wheel dev.

Zero	on success.
Non-zero	on failure.
dev l	Filter wheel device handle.
	Pointer to where the filter wheel filter count willbe placed.
	Non-zero dev l filter l

_ 3.37 _

LIBFLIAPI **FLIStepMotor** (flidev_t dev, long steps)

Step the filter wheel or focuser motor of a given device.

Step the filter wheel or focuser motor of a given device. Use this function to move the focuser or filter wheel dev by an amount steps.

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:		lter wheel or focuser device handle.
	steps Ni	umber of steps to move the focuser or fil-
	ter	wheel.
See Also:	FLIGetStepp	erPosition

LIBFLIAPI **FLIGetStepperPosition** (flidev_t dev, long* position)

Get the stepper motor position of a given device.

Get the stepper motor position of a given device. Use this function to read the stepper motor position of filter wheel or focuser dev.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev	Filter wheel or focuser device handle.
	position	Pointer to where the postion of the stepper
		motorwill be placed.
See Also:	FLIStepMoto	r

_____ 3.39 _____

LIBFLIAPI FLIHomeFocuser (flidev_t dev)

Home a given focuser.

Home a given focuser. Use this function to home focuser dev.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	dev Focus	ser device handle.

This page was generated with the help of DOC++

http://www.linuxsupportline.com/~doc++

May 19, 2003

33

3.38

_ 3.40 __

LIBFLIAPI FLICreateList (flidomain_t domain)

Creates a list of all devices within a specified domain.

Creates a list of all devices within a specified domain. Use FLIDeleteList() to delete the list created with this function. This function is the first called begin the iteration through the list of current FLI devices attached.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:		Domain to search for devices, set to zero to search all domains. This parameter must contain the device type.
]	FLIDeleteL FLIListFirst FLIListNex	 t

LIBFLIAPI FLIDeleteList (void)

3.41

Deletes a list of devices created by FLICreateList()

Deletes a list of devices created by FLICreateList()

Return Value:	Zero	on success.
	Non-zero	on failure.
See Also:	FLICreateList	
	FLIListFirst	
	FLIListNext	

This page was generated with the help of DOC++

LIBFLIAPI **FLIListFirst** (flidomain_t* domain, char* filename, size_t fnlen, char* name, size_t namelen)

Obtains the first device in the list.

Obtains the first device in the list. Use this function to get the first domain, filename and name from the list of attached FLI devices created using the function FLICreateList(). Use FLIListNext() to obtain more found devices.

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	domain	Pointer to where to domain of the device will be placed.
	filename	Pointer to where the filename of the device will be placed.
	fnlen	Length of the supplied buffer to hold the filename.
	name	Pointer to where the name of the device will be placed.
	namelen	Length of the supplied buffer to hold the name.
See Also:	FLICreateLis FLIDeleteLis FLIListNext	

LIBFLIAPI **FLIListNext** (flidomain_t* domain, char* filename, size_t fnlen, char* name, size_t namelen)

Obtains the next device in the list.

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

3.43

May 19, 2003

_ 3.42 _

Obtains the next device in the list. Use this function to get the next domain, filename and name from the list of attached FLI devices created using the function FLICreateList().

Return Value:	Zero	on success.
	Non-zero	on failure.
Parameters:	domain	Pointer to where to domain of the device will be placed.
	filename	Pointer to where the filename of the device will be placed.
	fnlen	Length of the supplied buffer to hold the filename.
	name	Pointer to where the name of the device will be placed.
	namelen	Length of the supplied buffer to hold the name.
See Also:	FLICreateLis	t
	FLIDeleteLis	t
	FLIListFirst	

This page was generated with the help of DOC++ http://www.linuxsupportline.com/~doc++

May 19, 2003